


⚠ Warning:

1. Please read this manual before start the installation. Manual version upgrade without notice.
2. Memo: If the flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
3. Please cut off the power supply before installation.



⚠ Safety Messages:

1. Installation, mounting or works on the electrical connection may only be carried out by an approved electrician.
2. Do not cover the product - provide free air circulation!
3. Do not open the lamps without an approved electrician.
4. This manual is for the below item, please read it carefully before installation.
5. Operate the product only when it functions properly.

It is recommended that these luminaires are installed and fitted by a qualified electrician, ensuring the installation complies with current IEE wiring regulations & local building control. These products are designed for connection to a 240V~50Hz supply.

Any faulty, broken or damaged luminaires should be replaced immediately. **Please Note:** The limited warranty shall be deemed null and void in the following circumstances: Failure by the installer, end user or any third party to exercise caution to protect any covered product or part from outside damage, adverse temperature (normal operating ambient temperature -20 ~ +40°C), humidity conditions, fluctuations in the electrical system or physical abuse as well as failure related to workmanship in the installation of the products or parts.

● Instruction:

1. Familiarise yourself with the connections and suitable locations for the LED panel. Ensure the mains supply is safely isolated.
2. The panel can be installed into suitable suspended ceilings or surface-mounted using the relevant kit (sold separately)
3. This product is suitable for both 15mm & 25mm T Grid ceilings. (Please ensure the ceiling can support the weight of the panel(s) to be fitted.)
4. The driver can be located on the rear of the panel if needed; however, it is advised that you locate it alongside the LED panel on an adjacent tile whenever possible.
5. Connect your mains supply to the LED driver, Live - Brown & Blue - Neutral.
6. As a Class II luminaire, it does not require an Earth connection.
7. Place the driver in the ceiling void; ensure you do not cover the driver in insulation, it must always remain in free air space. Connect the plug from the driver to the LED panel, twist and lock the connection.
8. Carefully install the panel into the ceiling, ensuring you take care not to damage the back of the panel by using excessive force and allow it to drop into the T grid, turn on the power and test.

● Specification:

Power Supply:	240V 50Hz
Operating Temperature:	-20°C - +40°C
IP Rating:	IP40
Driver:	Flicker free
Kelvin:	4000K
Lumens:	3600lm
CRI:	Ra>80
Wattage:	30W
Life Expectancy:	50000 hrs
Energy Class:	E

